

JACKSON TRAP ASSEMBLY INSTRUCTIONS

Product No. 3010T05: complete trap with 2 sticky liners (TAD)

Product No. 3010T07: trap with wire hanger only

Product No. 3010T10: trap only

Product No. 40PHT03: Jackson sticky liner (Dry Touch)

Product No. 3010T06: Jackson sticky liner (pair) with TAD trap coating


Components:

1 Jackson trap

Sticky liner

1 wire hanger

1 dispenser holder




How to assemble:

- 1 Fold open Jackson trap to form a tent shape.
- 2 Remove lure from foil pack (Avoid touching dispenser surface with fingers.).
- 3 Insert plastic or rubber dispenser only into the middle notch of the dispenser holder.
- 4 Slide dispenser holder onto side of trap so that the lure is on the inside and the two legs are on the outside.
- 5 Peel apart face-to-face sticky liners and slide one liner into trap.
- 6 Attach metal hanger as illustrated and hang trap in desired location.
- 7 Replace inserts as required.

NOTE TO USER:

To prolong storage life, refrigerate or freeze unused dispensers in their foil packets.

To avoid contamination, use tweezers or rubber gloves when handling dispensers.



DISTRIBUTIONS
SOLIDA^{INC.}

solida.ca

info@solida.ca

418-826-0900