



# SWD TRAP ASSEMBLY INSTRUCTIONS

Product No : 3010TDAT

For monitoring **Spotted Wing Drosophila**  
(*Drosophila suzukii*)

## Components:

Jar • Lid • Wire Hanger • Lure (sold separately)



## How to assemble:

- 1 Remove lid and wire hanger combo from jar.
- 2 Add drowning solution to jar. Recommended fluid capacity is 400 ml (1-2/3 cup).
- 3 The SWD lure will hang inside the top portion of the trap. Slide lure onto wire hanger through grommet on lure.
- 4 Pull hanger up and insert end through second hole in lid. Pull hanger until it seats fully into the lid. You may hear a click, indicating the hanger is seated.
- 5 Screw lid, hanger and lure combo onto jar. Hang using wire hanger.
- 6 Any additional lures can be stored at room temperature.

For customer support



solida.ca

info@solida.ca

418-826-0900